

# **USB (TYPE-C) CHARGER**

Accessory Name	Parts Number	Application	Issue Date	Publication No.
USB (TYPE-C) CHARGER UNIT	08E71-K0F-JF0	DAV425	September 2024	MII 55245
USB (TYPE-C) CHARGER ATTACHMENT	08U70-K0F-JF0	DAX125 MONKEY 125M		

### Introduction

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON Honda MOTORCYCLES, MOTOR SCOOTERS, ATVS OR SXS's.

### Honda Dealer:

Please give a copy of these instructions to your customer.

#### Customer

Because the installation of this accessory requires specialized knowledge, special tools and equipment, it is recommended to only install it at a dealer with qualified technicians.

### **How To Read These Symbols**

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual.

CAUTION You CAN be HURT if you don't follow instructions.

**MOTICE** The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

**NOTE** Things you want to know, things that are useful to know.

Follow the instructions of the Service Manual.

Follow the other instruction symbols of the "Basic Shop Manual".

### **Other Instruction Symbols**

The symbols used throughout these instructions show specific "Warnings and Notices".

Refer to the "Basic Shop Manual" for the description of each symbol.

## **INFORMATION**

### **ACAUTION**


• To prevent burns, allow the engine, exhaust system, radiator, etc., to cool before installing the accessory.

### NOTE:

- Heat the bonding surfaces with a hair dryer if the ambient air temperature is below 21°C (70°F).
- The adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.
- Take care not to damage the painted surfaces of the motorcycle.
- Reinstall the removed parts on the motorcycle and make sure that wires and harnesses are not pinched.
- After reconnecting the battery, refer to the Owner's Manual and set the meter.
- After this accessory installation, check the lights (e.g. right/left turn signal lights and brake lights) for proper operation.
- · Save all removed parts unless otherwise indicated.

### **PARTS LIST**

### **<USB CHARGER UNIT>**



No.	Parts Name	Qty	Parts No.	
(1)	USB charger unit	1	-	
(2)	Cover	1	-	
(3)	5 x 12 mm screw	1	93903-25280	
(4)	Wire tie	1	35701-MG9-950	
(5)	Сар	2	91456-371-770	
(6)	8 x 55 mm socket bolt	2	-	
(7)	Collar	2	-	

### **<USB CHARGER ATTACHMENT>**


08E71-K0F-JF0


Component	No.	Parts Name	Qty	Parts No.
	(8)	USB Charger Bracket	1	-
	(9)	Clip nut	1	-
(8) $(9)$				


# **TORQUE INFORMATION**


Refer to the Service Manual for the torque values of the removed parts. (11)


## **INSTALLATION**























9. Install the motorcycle's parts in the reverse order of removal.Confirm that any harness is not caught or too tight.