

HONDA

INSTALLATION INSTRUCTIONS


Accessory
LOAD LEVELING SUSPENSION SYSTEM
 P/N 08Z70-HL4-A51 ('16)
 P/N 08Z70-HL4-M50 (After '16)

Application
SXS1000M3/M3P/M3LE

Publication No.
MII 15262
 Issue Date
REVISED December 2016

Honda Dealer: Please give a copy of these instructions to your customer.

PARTS LIST



No.	Description	Qty
(1)	Rear shock absorber	2
(2)	12 mm flange lock nut	4
(3)	Installation Instructions URL	1

TOOLS REQUIRED

Box-end wrench (17 mm)

Torque wrench

TORQUE CHART

Tighten all screws, bolts, and nuts to their specified torque values. Refer to the Service Manual for the torque values of the removed parts.

Item	N·m	kgf·m	lbf·ft
12 mm flange lock nut	64	6.5	47

USE AND CARE INFORMATION

⚠ WARNING

The load leveling function of this accessory is not active when the vehicle is parked. Consequently, when the cargo bed is loaded and the SXS1000 is parked, the ground clearance can gradually reduce by up to 4.3 inches (110 mm).

- Ground clearance of a loaded, unsupported SXS1000 equipped with this accessory may decrease unexpectedly.
- Use caution when working under the SXS1000 while it is parked on all four wheels as objects or people below the unit could be crushed as the ground clearance gradually reduces.
- Unload the vehicle or support the chassis with a lift or stands before working underneath it.

INSTALLATION


⚠ CAUTION

- To prevent burns, allow the engine, exhaust system, radiator, etc., to cool before installing the accessory.

NOTE:

- Support the vehicle with a support block to raise the rear wheels off the ground when installing this accessory.
- Refer to the Owner's Manual or page 1-33 of the Service Manual for lift and support points.


1. Lift the bed as shown.





2. Remove the left rear wheel as shown.

- **Support the vehicle with an approved lift to raise the rear wheels off the ground.**



<Left side>



3. Remove the rear shock absorber as shown.



4. Install the accessory shock absorber as shown.



5. Install the left rear wheel in the reverse order of removal.
6. Repeat Steps 2 through 4 on the right side.
7. Lower the bed.